


Ethernet Network Setup

1. Plug the Ethernet cable in to the back of the reader and to an active internet port.
2. Plug the power cable into the back of the reader and into an electrical outlet.

Your reader screen should now show  in the top right corner.

Having trouble getting connected to Ethernet?

