Getting US15 Connected with Static IP Address

Static IP Connection

- 1) Press M/ \downarrow to display the menu options.
- 2) Arrow right to Comm and press Enter.
- 3) Select Ethernet and press Enter.
- 4) Arrow down to DHCP.
- 6) Press M/ L to turn DHCP OFF.
- 5) Arrow up to IP address and press M/4.
- 6) Enter the desired IP address and use the down to switch between each set.

Example: IP address: (192.168.10.201)

Subnet mask: (255.255.255.0)

Gateway address: (0.0.0.0)

- 7) Arrow down until "Confirm (OK)" is highlighted and press M/↓ .
- 8) Repeat steps 5 through 7 for subnet mask, gateway, and DNS.

Main Menu			
User Mgt.	сомм.	System	Personalize
Data Mgt.	USB Manager	Attendance Search	Short Message
	➡		
	Comm.		
Ethernet			
🥯 Serial Comm			
PC Connection			
Wireless Network			
Cloud Server Settings			
📷 Wiegand Setup			
	Ethernet		
IP Address			192.168.10.124
Subnet Mask			255.255.255.0
Gateway			192.168.10.254
DNS			8.8.8.8
TCP COMM.Port			4370
DHCP			ON