

In addition to employee clocking, the Reader PIN can be used for reader security. It is required to set an Admin lock, but recommended for the Enroll lock, as well.


Here are the two types of security locks:

Admin Lock – Locks the reader, requiring an authorized employee # and PIN, fingerprint, or badge to access the menu pages.

**Enroll Lock** – Requires an authorized employee # and PIN, fingerprint, or badge to access only the menu pages that allow enrollment.

\*Admin Lock required to use Enroll Lock.

## Unlocking the reader with an Admin or Enroll PIN:















## **Enroll Menu**





To Set Admin Lock Setup tab > Reader Download Step One: 45 Set 4567 Usernames with Admin access must Bianchi, Kenneth ☑ Download 1 User ☐ Reader Only first have a numeric password. 3. Set a numeric password 1. Choose designated username to 2. Click Download allow Admin access to reader 4. Save Changes Save Changes Step Two: Now "Admin" is an option in the Ma dropdown menu under Reader Access. 45 Bianchi, Kenneth 1 Admin ∨ ☑ Download Reader Only □ Clear Ma 2. Choose Admin 1. Click Download 3. Save Changes Save Changes

## To Set Enroll Lock

Once there is an Admin set, "Enroll" is an option in the dropdown menu under Reader Access.

